


Index	2	Operation	5
Safety information	2	DMX out	5
Technical	3	Autofade	7
Content	3	DMX in	9
Specifications	3	Cable test mode	10
Instruction	4	DIM control	14
		Dout control	15
		Synchronal singal output	16



SAFETY INFORMATION

<p>Always switch off mains power of the driver before connecting or maintaining any fixtures!</p>	<p>Make sure all connectors are connected properly</p>	<p>Use a source of AC power that complies to local electrical codes</p>	<p>Block access below the work area when maintaining the unit</p>	<p>Do not stare into the LED</p>	<p>Ambiance Max. 40°</p>	<p>Qualified technician</p>
	<p>Don't modify or install genuine parts on this product</p>	<p>Don't install in a flammable or explosive area</p>	<p>Warning! Some surfaces can be hot</p>			

2023 CLS-LED BV. All rights reserved. Information subject to change without notice, CLS-LED BV and all affiliated companies disclaim liability for injury, damage direct or indirect loss, consequential or economic loss or any other loss occasioned by the use of, inability to use or reliance on the information contained in this manual. No part of this manual may be reproduced, in any form or by any means, without permission in writing from CLS-LED BV. Other legal information can be found in our General conditions, found on the back of your CLS-LED BV invoice, inside the CLS catalogue or on our website www.cls-led.com/General-Terms.pdf



CONTENT



The CLS D-ta DMX tester/addresser is shipped in one package containing the following items:

- CLS D-ta DMX tester/addresser
- Power supply 12VDC
- DMX test module
- 1 x XLR connector XLR 5 to XLR 3
- 1 x XLR connector XLR 3 to XLR 5

SPECIFICATIONS

Power supply:	12 VDC
Power consumption:	1A
Housing:	Aluminum
Weight:	0,75 Kg
Shipping Weight:	1,2 Kg
Measurements:	135 x 97 x 37 (hwxwd)
Shipping Dimensions:	80 x 240 x 170 mm (hwxwd)
DMX input:	DMX512
DMX output channels:	512 channels
DMX Signal connector:	XLR 5 pin (x2) Phone jack RJ11 (x2)
Ambient Temperature:	max. 40° C

This section shows how to operate the CLS D-ta DMX Tester.




- | | |
|------------------|----------------------------------|
| 1 Power Switch | 6 Hex / Decimal / Percent Button |
| 2 LCD Display | 7 DMX Signal Output: XLR 5 PIN |
| 3 LEVEL UP Key | 8 DMX Signal Input: XLR 5 PIN |
| 4 LEVEL DOWN Key | 9 DMX Signal Input / Output |
| 5 Function Keys | 10 Power Supply Input. |


OPERATION

DMX out


STEP-1 Press DMX OUT, the LCD will display:




STEP-2 Press [▶] and [◀] keys to select channel.



STEP-3 To set a range of consecutive channels at the same level, use the [↵] key. For example, to set channel 1 through 5, press [—] and the LCD will display:




Press [▶] key until the LCD displays:




Press [▶] and [◀] keys to set the DMX channel.

You can also hold [▶] and press [◀] key or hold [◀] and press [▶] to quickly increase or decrease the DMX channel.




You can also hold [▲] and press [▼] key or hold [▼] and press [▲] to quickly increase or decrease the DMX level. C001 to C005 are output at 1BH.




Hold [▲] and press [▼] key or hold [▲] and press [▼] key to quickly set the level at 0%, 50% and 100%.


STEP-5 The LCD readout in DMX level: Hex, Decimal or Percent. Press [HEX/%] button to select.




STEP-6 Three DMX send frequencies are available when generating DMX from the tester.



DMX send frequency 20/S



DMX send frequency 40/S



DMX send frequency 44/S

20/s DMX Send Frequency: 20 times per second. (20/s)

40/s DMX Send Frequency: 40 times per second. (40/s),


can be used to test devices at a faster rate should that rate be required for your application.

44/s DMX Send Frequency: 44 times per second. (44/s),

can be used to test devices at a faster rate should that rate be required for your application.

(For more information, please refer to 2-9 DOut protocol.)

STEP-7 When DMX OUT mode, if there is a DMX signal input, the LCD will display:



Above means the received DMX IN channel 1 is 2FH and channel 2-5 is 00H.

This function can be used to test the cable. Plug the male and female ends of the data cable into the DMX OUT and DMX IN ports individually, if the data was received is the same with the data was sent, it means the cable is in good condition. LCD readout for DMX IN is in Hex. It is irrelevant for FadeOut.

Autofade

Setting Signal channel or a range of consecutive channels automatically fade.

STEP-1 In DMX OUT mode press [DMX OUT] to enter AutoFade function and the LCD will display:

```
FadeOut 175us 20/s [m]
C001-----= 00%
no DMX in
```

STEP-2 DMX level automatically ramping from 0 to 100% and back.

```
FadeOut 175us 20/s [m]
C001-----= 10%
no DMX in
```

STEP-3 Press [▲] and [▼] keys to set autofade speed.

STEP-4 Press [▶] and [◀] keys to select AutoFade channel.

```
FadeOut 175us 20/s [m]
C002-----= 20%
no DMX in
```

STEP-5 To AutoFade a range of successive channels, follow below:
Press [—] key and the LCD will display:

```
FadeOut 175us 20/s [m]
C002-003= 20%
no DMX in
```

The operation for the AutoFade will be: **C002:** 0% --> 100% --> 0%
C003: 0% --> 100% --> 0%
C002: 0% --> 100% --> 0%.

STEP-6 Press [▶] and [◀] keys to select AutoFade end channel,
If pressing [▶], the LCD will display as below:

```
FadeOut 175us 20/s [m]
C002-004= 20%
no DMX in
```

You can also hold [▶] and press [◀] key or hold [◀] and press [▶] to quickly increase or decrease the DMX channel.

STEP-7 Press [◀] to decrease the AutoFade end channel. The LCD will display as below:

```
FadeOut 175us 20/s [m]
C002-003= 20%
no DMX in
```

2. Setting AutoFade Send Frequency

Three AutoFade send frequency are available: 20/s,40/s and 44/s.

```
FadeOut 175us 20/s [m]
C001-----= 10%
no DMX in
```

DMX send frequency:20/s

```
FadeOut 175us 40/s [m]
C001-----= 00%
no DMX in
```

DMX send frequency:40/s

```
FadeOut 175us 44/s [m]
C001-----= 00%
no DMX in
```

DMX send frequency:44/s

(For more information, please refer to 2-9 DOut protocol.)

3.DMX IN in AUTO FADE Mode


STEP-1 In AUTO FADE mode, if there is a DMX signal input, LCD will display:

```
FadeOut 175us 20/s [m]
C002-004= 20%
C001: 00.34.34.34.00.
```

Above means channel 2 to 4 for DMX IN are 34H (20%)
LCD readout for DMX IN is in Hex. It is irrelevant for FadeOut.

DMX IN

STEP-1 Press [DMX IN] and the LCD will display:



Start Code: DMX IN start code level which is received.


DMX IN Receiving Frequency: It shows how many times DMX IN signal are received. When DMX IN signal is received over than 99 times, it will switch to Frequency. (How many times per second.)

%/H/D: Percent/ Hexadecimal or Decimal.

C001: DMX IN start channel.

While receiving DMX IN data, the LED in the DMX IN button will be lighted.

STEP-2 Press [▶] and [◀] or [▲] and [▼] keys to select start channel. Press [▼] and the LCD will display:



Clearing DMX IN levels

To clear DMX IN levels, first remove the DMX IN XLR then press [DMX IN] and the LCD will display

DmxIn	00H-00	%
C006:	00.00	00.00.00.00
C011:	00.00	00.00.00.00
C016:	00.00	00.00.00.00
C021:	00.00	00.00.00.00
C026:	00.00	00.00.00.00
C031:	00.00	00.00.00.00

Cable test mode

STEP-1 Press [FUNC] to enter Menu and the LCD will display:

Function
▶ F1: Cable test
F2: Code Mode
F3: Backlight
F4: Battery
F5: DIn Protocol
F6: DOut Protocol

STEP-2 Press [▲] and [▼] to select F1: Cable

Function
▶ F1: Cable test
F2: Code Mode
F3: Backlight
F4: Battery
F5: DIn Protocol
F6: DOut Protocol

STEP-3 Press [FUNC] again to enter and the LCD will display:

Cable Test	-out-	-in-
▶ 1:Gnd	1:Gnd	1:Gnd
2:D-	2:D-	2:D-
3:D+	3:D+	3:D+
4:Nc	4:Nc	4:Nc
5:Nc	5:Nc	5:Nc

STEP-4 Plug the male and female ends of the data cable into the DMX OUT and DMX IN ports individually, the LCD will display:

Cable Test	-out-	-in-
▶ 1:Gnd	✓ 1:Gnd	1:Gnd
2:D-	2:D-	2:D-
3:D+	3:D+	3:D+
4:Nc	4:Nc	4:Nc
5:Nc	5:Nc	5:Nc

STEP-5 Press [▼] to test next cable and the LCD will display:

Cable Test	-out-	-in-
1:Gnd	1:Gnd	1:Gnd
▶ 2:D-	✓ 2:D-	2:D-
3:D+	3:D+	3:D+
4:Nc	4:Nc	4:Nc
5:Nc	5:Nc	5:Nc

Cable Test	-out-	-in-
1:Gnd	1:Gnd	1:Gnd
▶ 2:D-	2:D-	2:D-
3:D+	3:D+	3:D+
4:Nc	4:Nc	4:Nc
5:Nc	5:Nc	5:Nc


Cable Test	-out-	-in-
1:Gnd	1:Gnd	1:Gnd
▶ 2:D-	2:D-	2:D-
3:D+	✓ 3:D+	3:D+
4:Nc	4:Nc	4:Nc
5:Nc	5:Nc	5:Nc

the cable (D-) is connected.

the cable (D-) is disconnected.

the signal cable is abnormal.


STEP-7 If the male and female ends of the data cable can not plug into the DMX OUT and DMX IN ports, you can use a test module, please use as below:
 Plug the male end of the data cable into the DMX OUT ports and plug the female end of the data cable into the test module.




STEP-8 Connecting with a test module and choose "1:GND", if the first LED on the left is lighted, it means the connection is correct. You can use the same way to test D+ and D-.

Code mode


STEP-1 Press [FUNC] to enter Menu and the LCD will display:




STEP-2 Press [▲] and [▼] to select F2: Code Mode.




STEP-3 Press [FUNC] again to enter and the LCD will display:




STEP-4 If connecting a fixture, press scene [1] key. Press scene [OFF] key and the CLS D-ta DMX Tester LCD will display:



STEP-5 Press [▶] and [◀] to choose a code.




STEP-6 Press [▲] to clear and the LCD will display.




LCD backlight


STEP -1 Press [FUNC] to enter Menu and the LCD will display:



STEP-2 Press [▲] and [▼] to select F3: Backlight




STEP-3 Press [FUNC] again to enter and the LCD will display:




1 minute: If stopped using, backlight will automatically turn off after 1 minute.
20 minute: If stopped using, backlight will automatically turn off after 20 minutes.
Always on: Backlight always ON
Always off: Backlight always OFF

Battery Display


STEP-1 Press FUNC to enter Menu and the LCD will display:



STEP-2 Press [▲] and [▼] to select F4: Battery.




STEP-3 Press [FUNC] again to enter and the LCD will display:




Dim control


STEP-1 Press [FUNC] to enter Menu and the LCD will display:




STEP-2 Press [▲] and [▼] to select F5: DIN Protocol.



STEP-3 Press [FUNC] again and the LCD will display:




STEP-4 When extending a DMX IN signal and the LCD will display:




Dout control


STEP-1 Press [FUNC] to enter Menu and the LCD will display:




STEP-2 Press [▲] and [▼] to select F6: DOut Protocol.



STEP-3 Press [FUNC] again and the LCD will display:




STEP-4 Press [▲] and [▼] to adjust break time.




Press [▲] to increase Break time, up to 300Us, Press [▼] to decrease Break time, down to 60uS.


STEP-5 Press [▶] and [◀] and the LCD will display:



STEP-6 Press [▲] and [▼] keys to adjust DMX send frequency: 20/s, 40/s and 42/s.



DMX Send Frequencies: 20s



DMX Send Frequencies: 40s


SYNCHRONAL SIGNAL OUTPUT

STEP-1 For further analysis of the DMX signal, the tester can be connected to a scope.

STEP-2 If the CLS D-ta DMX tester/addresser receives a CH001 = 42H DMX IN signal, you can measure from SYNC of TO SCOPE to RX ground, as the wave below:

CH-00 in circle is the DMX wave of RX ground.

CH-01 in circle is the synchronal signal wave of SYNC.



STEP-3 If the CLS D-ta DMX Tester sent a CH001 = 42H DMX IN signal, you can measure from SYNC of TO SCOPE to TX ground, as the wave below:

CH-00 in circle is the DMX wave of TX ground.

CH-01 in circle is the synchronal signal wave of SYNC.

